



Contact **SAMSUNG WORLDWIDE**
If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Country	Customer Care Centre ☎	Web Site
AUSTRIA	0810 - SAMSUNG (7267864, € 0.07/min)	www.samsung.com/at
BELGIUM	02 201 2418	www.samsung.com/be www.samsung.com/be_fr
CZECH REPUBLIC	800 - SAMSUNG (800-726786) Distributer pro Českou republiku: Samsung ZČL, česká organizační složka, Oasis Florenc, Sokolovská394/17, 150 00, Praha 8	www.samsung.com/cz
DENMARK	8 - SAMSUNG (7267864)	www.samsung.com/dk
IRE	0818 717 100	www.samsung.com/ie
FINLAND	30 • 6227 515	www.samsung.com/fi
FRANCE	01 4863 0000	www.samsung.com/fr
GERMANY	01805 - SAMSUNG (7267864, € 0.14/Min)	www.samsung.de
HUNGARY	06 - 80 - SAMSUNG (7267864)	www.samsung.com/hu
ITALIA	800 • SAMSUNG (7267864)	www.samsung.com/it
LUXEMBURG	02 261 03 710	www.samsung.com/lu
NETHERLANDS	0900-SAMSUNG (0900-7267864) (€ 0.10/Min)	www.samsung.com/nl
NORWAY	3 - SAMSUNG (7267864)	www.samsung.com/no
POLAND	0 801 1SAMSUNG(172678) 022 - 607 - 93 - 33	www.samsung.com/pl
PORTUGAL	808 20 - SAMSUNG (7267864)	www.samsung.com/pt
SLOVAKIA	0800 • SAMSUNG (7267864)	www.samsung.com/sk
SPAIN	902 • 1 • SAMSUNG (902 172 678)	www.samsung.com/es
SWEDEN	0771 728 7864 (SAMSUNG)	www.samsung.com/se
SWITZERLAND	0648 - SAMSUNG (7267864, CHF 0.08/min)	www.samsung.com/ch
U.K	0845 SAMSUNG (7267864)	www.samsung.com/uk
TURKEY	444 77 11	www.samsung.com/tr
BELARUS	810-800-500-55-500	-
ESTONIA	800-7267	www.samsung.com/ee
LATVIA	8000-7267	www.samsung.com/lv
LITHUANIA	8-800-77777	www.samsung.com/lt
MOLDOVA	00-800-500-55-500	-
KAZAHSTAN	8-10-800-500-55-500	www.samsung.com/kz_ru
KYRGYZSTAN	00-800-500-55-500	-
RUSSIA	8-800-555-55-55	www.samsung.ru
TADJIKISTAN	8-10-800-500-55-500	-
UKRAINE	8-800-502-0000	www.samsung.com/ua www.samsung.com/ua_ru
UZBEKISTAN	8-10-800-500-55-500	www.samsung.com/uz_ru



BN68-02360A-02

SERIES
4

LCD TV user manual

imagine the possibilities

Thank you for purchasing this Samsung product.
To receive more complete service, please register
your product at

www.samsung.com/register

Model _____ Serial No. _____



Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance. Product design and specifications may be changed without notice.

□ License



TruSurround HD, SRS and  symbol are trademarks of SRS Labs, Inc. TruSurround HD technology is incorporated under license from SRS Labs, Inc.




Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.

□ Digital TV Notice

1. Functionalities related to Digital TV(DVB) are only available in countries/areas where DVB-T (MPEG2 and MPEG4 AVC) digital terrestrial signals are broadcasted or where you are able to access to a compatible DVB-C(MPEG2 and MPEG4 AAC) cable-TV service. Please check with your local dealer the possibility to receive DVB-T or DVB-C signal.
2. DVB-T is the DVB European consortium standard for the broadcast transmission of digital terrestrial television and DVB-C is that for the broadcast transmission of digital TV over cable. However, some differentiated features like EPG (Electric Programme Guide), VOD (Video on Demand) and so on, are not included in this specification. So, they cannot be workable at this moment.
3. Although this TV set meets the latest DVB-T and DVB-C standards, as of [August, 2008], the compatibility with future DVB-T digital terrestrial and DVB-C digital cable broadcasts cannot be guaranteed.
4. Depending on the countries/areas where this TV set is used some cable-TV providers may charge an additional fee for such a service and you may be required to agree to terms and conditions of their business.
5. Some Digital TV functions might be unavailable in some countries or regions and DVB-C might not work correctly with some cable service providers.
6. For more information, please contact your local Samsung customer care centre.

□ Precautions When Displaying a Still Image





A still image may cause permanent damage to the TV screen

- Do not display a still image and partially still on the LCD panel for more than 2 hours as it can cause screen image retention. This image retention is also known as 'screen burn'. To avoid such image retention, reduce the degree of brightness and contrast of the screen when displaying a still image.
-  Watching the LCD TV in 4:3 format for a long period of time may leave traces of borders displayed on the left, right and centre of the screen caused by the difference of light emission on the screen. Playing a DVD or a game console may cause a similar effect to the screen. Damages caused by the above effect are not covered by the Warranty.
- Displaying still images from Video games and PC for longer than a certain period of time may produce partial after-images. To prevent this effect, reduce the brightness and contrast when displaying still images.

CONTENTS

GENERAL INFORMATION	
■ Viewing the Control Panel.....	2
■ Accessories.....	2
■ Viewing the Connection Panel.....	3
■ Remote Control	5
■ Installing Batteries in the Remote Control	5
OPERATION	
■ Viewing the menus	6
■ Placing Your Television in Standby Mode.....	7
■ Plug & Play Feature.....	7
■ Viewing the Display	8
CHANNEL CONTROL	
■ Configuring the Channel Menu.....	8
■ Managing Channels	11
PICTURE CONTROL	
■ Configuring the Picture Menu	13
■ Using Your TV as a Computer (PC) Display.....	15
■ Setting up the TV with your PC.....	16
SOUND CONTROL	
■ Configuring the Sound Menu	17
■ Selecting the Sound Mode	18
SETUP	
■ Configuring the Setup Menu.....	19
INPUT / SUPPORT	
■ Configuring the Input Menu	22
■ Configuring the Support Menu.....	22
RECOMMENDATIONS FOR USE	
■ Teletext Feature.....	24
■ Installing the Stand	25
■ Installing the Wall Mount Kit.....	25
■ Using the Anti-Tilt Kensington Lock	26
■ Securing the Installation Space	26
■ Securing the TV to the Wall.....	27
■ Troubleshooting	28
■ Specifications	31


Symbol

	Note		One-Touch Button		TOOLS Button		Press
---	------	---	------------------	---	--------------	---	-------

GENERAL INFORMATION

Viewing the Control Panel

- ⑦ The product colour and shape may vary depending on the model.
- ⑦ You can use a button by pressing the side panel buttons.



- ① **SOURCE** : Toggles between all the available input sources. In the on-screen menu, use this button as you would use the **ENTER** button on the remote control.
- ② **MENU**: Press to see an on-screen menu of your TV's features.
- ③ **- / +**: Press to increase or decrease the volume. In the on-screen menu, use the **- / +** buttons as you would use the **▲** and **▼** buttons on the remote control.
- ④ **< CH >**: Press to change channels. In the on-screen menu, use the **< CH >** buttons as you would use the **▼** and **▲** buttons on the remote control.
- ⑤ **⏻ (POWER)**: Press to turn the TV on and off.
- ⑥ **REMOTE CONTROL SENSOR**: Aim the remote control towards this spot on the TV.
- ⑦ **POWER INDICATOR**: Blinks and turns off when the power is on and lights up in stand-by mode.
- ⑧ **SPEAKERS**

Accessories

Remote Control & Batteries (AAA x 2)

Power Cord

Cover-Bottom

Stand Screw X 4 (32inch model only)

Cleaning Cloth

(M4 X L 16) (M4 X L 14)

- Owner's Instructions
- Warranty card
- Safety Guide


- ⑦ Please make sure the following items are included with your LCD TV. If any items are missing, contact your dealer.
- ⑦ Warranty card / Safety Guide (Not available in all locations)
- ⑦ The items colour and shape may vary depending on the model.


Specifications





Model Name	LE26B450	LE32B450
Screen Size (Diagonal)	26 inch	32 inch
PC Resolution (Optimum)	1360 x 768 @ 60Hz	1360 x 768 @ 60Hz
Sound (Output)	5W X 2	10W X 2
Dimensions (WxDxH)		
Body	670 x 75 x 455 mm	800 x 85 x 531 mm
With stand	670 x 216 x 495 mm	800 x 252 x 577 mm
Weight	8 kg	12 kg
With Stand		
Environmental Considerations		
Operating Temperature	10°C to 40°C (50°F to 104°F)	10°C to 40°C (50°F to 104°F)
Operating Humidity	10% to 80%, non-condensing	10% to 80%, non-condensing
Storage Temperature	-20° C to 45°C (-4°F to 113°F)	-20° C to 45°C (-4°F to 113°F)
Storage Humidity	5% to 95%, non-condensing	5% to 95%, non-condensing
Stand Swivel	0°	-10° ~ 10°

- ⑦ Design and specifications are subject to change without prior notice.
- ⑦ This device is a Class B digital apparatus.
- ⑦ For the power supply and Power Cons

Viewing the Connection Panel

Issue	Solution
Others	
Picture is not shown in full screen.	<ul style="list-style-type: none"> Black bars on each side will be shown on HD channels when displaying upscaled SD (4:3) contents. Black bars on Top & Bottom will be shown on movies that have aspect ratios different from your TV. Adjust picture size option on your external device or TV to full screen.
Remote control does not work.	<ul style="list-style-type: none"> Replace the remote control batteries with correct polarity (+ -). Clean the transmission window located on the top of the remote. Try pointing the remote directly at the TV from 5-6 feet away.
Can not control TV power or volume with Cable/Sat top box remote control.	<ul style="list-style-type: none"> Programme the Cable/Sat top box remote control to operate the TV. Refer to Cable/Sat user manual for SAMSUNG TV code.
Not Supported Mode' message.	<ul style="list-style-type: none"> Check the supported resolution of the TV and adjust the external device's output resolution accordingly. Refer to resolution settings in this manual.
Plastic smell from TV.	<ul style="list-style-type: none"> This smell is normal and will dissipate over time.
TV Signal information is unavailable in the Self Diagnostic Test menu.	<ul style="list-style-type: none"> This function is only available with digital channels with an Antenna (RF/Coax) connection.
TV is tilted to right or left side.	<ul style="list-style-type: none"> Remove the stand base from TV and reassemble.
Can not assemble stand base.	<ul style="list-style-type: none"> Make sure TV is placed on flat surface. If can not remove screws from TV, please use magnetized screw driver.
Channel menu is grey out. (unavailable)	<ul style="list-style-type: none"> Channel menu is only available when TV source is selected.
Your settings are lost after 30 minutes or every time TV is turned off.	<ul style="list-style-type: none"> If TV is in the Store Demo mode, it will reset audio and picture settings every 30 minutes. Please change from Store Demo mode to Home Use mode in the Plug & Play procedure. Press the SOURCE button to select TV mode, go to MENU → Setup → Plug & Play → ENTER [↵].
Intermittent loss of audio or video.	<ul style="list-style-type: none"> Check cable connections and reconnect. Can be caused by using overly rigid or thick cables. Make sure the cables are flexible enough for long term use. If wall mounting, we recommend using cables with 90 degree connectors.
You may see small particles if you look closely at the edge of the bezel surrounding the TV screen.	<ul style="list-style-type: none"> This is part of the product's design and is not a defect.
Scramble signal or Weak Signal No Signal with CAM CARD(C).	<ul style="list-style-type: none"> Check that CAM has CI Card installed into the common interface slot. Pull out CAM from the TV and insert into the slot again.
When turned off and 45 minutes later, TV is turned on itself.	<ul style="list-style-type: none"> It is normal, the TV operate OTA (Over The Air) function itself to upgrade firmware downloaded during watching.
Recurrent picture/sound issue.	<ul style="list-style-type: none"> Check and change signal/source.
<p> This TFT LCD panel uses a panel consisting of sub pixels which require sophisticated technology to produce. However, there may be few bright or dark pixels on the screen. These pixels will have no impact on the performance of the product.</p>	



-  The product colour and shape may vary depending on the model.
-  Whenever you connect an external device to your TV, make sure that power on the unit is turned off.
-  When connecting an external device, match the colour of the connection terminal to the cable.
- 1 DIGITAL AUDIO OUT (OPTICAL)**
- Connects to a Digital Audio component such as a Home theatre receiver.
-  When the HDMI IN jacks are connected, the **DIGITAL AUDIO OUT (OPTICAL)** jack on the TV outputs 2 channel audio only. If you want to hear 5.1 channel audio, connect the Optical jack on the DVD / Blu-ray player or Cable / Satellite Box directly to an Amplifier or Home Theatre, not the TV.
- 2 PC IN**
- Connect to the video output jack on your PC.
- 3 ANT IN**
- Connects to an antenna or cable TV system.
- 4 PC / DVI AUDIO IN**
- Connect to the audio output jack on your PC.
 - DVI audio outputs for external devices.
- 5 AUDIO OUT [R-AUDIO-L]**
- Connect RCA audio cables to **AUDIO OUT [R-AUDIO-L]** on the rear of your set and the other ends to corresponding audio in connectors on the Amplifier or DVD Home Theatre.

6 HDMI IN (1DVI), 2, 3

- Connects to the HDMI jack of a device with an HDMI output.
- ② No sound connection is needed for an HDMI to HDMI connection.
- ② Use the **HDMI IN (1DVI)** jack for DVI connection to an external device. Use a DVI to HDMI cable or DVI-HDMI adapter (DVI to HDMI) for video connection and the **PC / DVI AUDIO IN** jacks for audio.
- ② You can also use the ports to connect to a PC.
- ② What is HDMI?

'High Definition Multimedia interface' allows the transmission of high definition digital video data and multiple channels of digital audio.

The HDMI / DVI terminal supports DVI connection to an extended device with the appropriate cable (not supplied). The difference between HDMI and DVI is that the HDMI device is smaller in size, has the HDCP (High Bandwidth Digital Copy Protection) coding feature installed, and supports multi - channel digital audio.

- ② The TV may not output sound and pictures may be displayed with abnormal colour when DVD / Blu-ray player / Cable Boxes / Satellite receivers supporting HDMI versions older than 1.3 are connected. When connecting an older HDMI cable and there is no sound, connect the HDMI cable to the **HDMI IN (1DVI)** jack and the audio cables to the **PC / DVI AUDIO IN** jacks on the back of the TV. If this happens, contact the company that provided the DVD / Blu-ray player / Cable Box / Satellite receiver to confirm the HDMI version, then request a firmware update. HDMI cables that are not 1.3 may cause annoying flicker or no screen display.

7 COMMON INTERFACE Slot

- When not inserting CI CARD in some channels, 'Scrambled Signal is displayed on the screen.
- The pairing information containing a telephone number, CI CARD ID, Host ID and other information will be displayed in about 2-3 minutes. If an error message is displayed, please contact your service provider.
- When the channel information configuration has finished, the message 'Updating Completed' is displayed, indicating that the channel list is now updated.
- ② You must obtain a CI CARD from a local cable service provider. Remove the CI CARD by carefully pulling it out with your hands since dropping the CI CARD may cause damage to it.
- ② Insert the CI-Card in the direction marked on it.
- ② The place of the **COMMON INTERFACE** Slot may be different depending on its model.
- ② CAM is not supported in some countries and regions. Check with your authorized dealer.

8 AV IN [VIDEO] / [R-AUDIO-L]

- Connect RCA cable to an appropriate external AV device such as VCR, DVD or Camcorder.
- Connect RCA audio cables to **[R-AUDIO-L]** on your set and the other ends to corresponding audio out connectors on the AV device.

9 KENSINGTON LOCK (depending on the model)

- The Kensington Lock (optional) is a device used to physically fix the system when used in a public place. If you want to use a locking device, contact the dealer where you purchased the TV.
- ② The location of the Kensington Lock may be different depending on its model.

10 COMPONENT IN

- Connect component video cables (optional) to component connector (P_r, P_b, Y) on the rear of your set and the other ends to corresponding component video out connectors on the DTV or DVD.
- If you wish to connect both the Set-Top Box and DTV (or DVD), you should connect the Set-Top Box to the DTV (or DVD) and connect the DTV (or DVD) to component connector (P_r, P_b, Y) on your set.
- The P_r, P_b and Y connectors on your component devices (DTV or DVD) are sometimes labelled Y, B-Y and R-Y or Y, Cb and Cr.
- Connect RCA audio cables (optional) to **[R-AUDIO-L]** on the rear of your set and the other ends to corresponding audio out connectors on the DTV or DVD.

11 EXT (RGB)

Input			Output	
Connector	Video	Audio (L / R)	RGB	Video + Audio (L / R)
EXT	O	O	O	Only TV or DTV output is available.

12 SERVICE

- Connector for software upgrades.

Issue		Solution
No Picture, No Video TV won't turn on.		<ul style="list-style-type: none">• Make sure the AC power cord is plugged in securely to the wall outlet and the TV.• Make sure the wall outlet is working.• Try pressing the POWER button on the TV to make sure the remote is working properly. If the TV turns on, it may be caused by Remote Control. To fix the Remote problem, refer to 'Remote control does not work' below.
	TV turns off automatically.	<ul style="list-style-type: none">• Check if the Sleep Timer is set to On in the Setup menu.• If connected the TV to your PC, check your PC power settings.• Make sure the AC power cord is plugged in securely to the wall outlet and the TV.• If there is no signal for about 10 ~ 15 minutes with Antenna/Cable connection, the TV will turn off.
No picture/Video.		<ul style="list-style-type: none">• Check cable connections, remove and reconnect all cables of TV and external devices)• Set your external device's (Cable/Set top Box, DVD, Blu-ray etc) video output to match the connections to the TV input. For example, external device's output: HDMI, TV's input: HDMI.• Make sure your connected device is powered on.• Make sure to select the TV's correct source by pressing the SOURCE button on the TV remote.
RF (Cable/Antenna) Connection Cannot receive all channels.		<ul style="list-style-type: none">• Make sure Antenna cable is connected securely.• Please try Plug & Play to add available channels to the channel list. Go to MENU - Setup - Plug & Play and wait for all available channels are stored.• Verify Antenna is positioned correctly.• Compression of video contents may cause picture distortion especially on fast moving pictures such as sports and action movies.• Low signal level can cause picture distortion. This is not a TV issue.
PC Connection 'Not Supported Mode' message.		<ul style="list-style-type: none">• Set your PC's output resolution and frequency so it matches the resolutions supported by the TV.
PC is always shown on source list even if not connected.		<ul style="list-style-type: none">• This is normal, PC is always shown on the source list even though a PC is not connected.
Video is OK but there is no audio with HDMI connection.		<ul style="list-style-type: none">• Check the audio output setting on your PC.

Troubleshooting


If you have any questions of TV, first refer to this list. If none of these troubleshooting tips apply, please visit 'www.samsung.com' site, then click on Support or contact Call Centre on list of last page.

Issue	Solution
Picture Quality	<p>First of all, please perform the Picture Test to confirm that your TV is properly displaying test image.</p> <ul style="list-style-type: none">Go to MENU - Support - Self Diagnosis - Picture Test <p>If the test image is properly displayed, the poor picture may caused by the source or signal.</p>
TV image does not look as good as it did in the store.	<ul style="list-style-type: none">If you have an analogue Cable/Set top box, upgrade to an Box. Use HDMI or Component cables to deliver HD picture quality.Cable/Satellite subscriber : Try HD(High Definition) stations from channel line up.Antenna connection: Try HD stations after performing Auto programme.Many HD channels are upscaled from SD(Standard Definition) contents.Adjust Cable/Set top box video output resolution to 1080i or 720p.Confirm that you are watching the TV at the minimum distance recommended based on the size and definition of the signal you are displaying.
Picture is distorted : macroblock, small block, dots, pixelization	<ul style="list-style-type: none">Compression of video contents may cause picture distortion especially on fast moving pictures such as sports and action movies.Low signal level or bad quality can cause picture distortion. This is not a TV issue.
Wrong or missing colour with Component connection.	<ul style="list-style-type: none">Make sure the Component cables are connected to the correct jacks. Incorrect or loose connections may cause colour problems or the screen will be blank.
Poor colour or brightness.	<ul style="list-style-type: none">Adjust Picture options in the TV menu. (Picture mode, Colour, Brightness, Sharpness)Adjust Energy Saving option in Setup menu.Try picture reset to view the default picture setting. (Go to MENU - Picture - Picture Reset)
Dotted line on the edge of screen.	<ul style="list-style-type: none">If picture size is set to Screen Fit, change to 16:9.Change cable/set top box resolution.
Picture is black and white with AV (Composite) input only.	<ul style="list-style-type: none">Connect video cable(Yellow) to Green jack of component input 1 of the TV.
Picture freezes or is distorted when changing channels or picture is delayed.	<ul style="list-style-type: none">If connected with cable box, please try to reset cable box. (reconnect AC cord and wait until cable box reboots. It may take up to 20 minutes.)Set output resolution of cable box to 1080i or 720p.
Sound Quality	<p>First of all, please perform the Sound Test to confirm that your TV audio is properly operating.</p> <ul style="list-style-type: none">Go to MENU - Support - Self Diagnosis - Sound Test <p>If the audio is OK, the sound problem may caused by the source or signal.</p> <ul style="list-style-type: none">Please check the volume of external device connected to your TV then, adjust the TV volume accordingly.
No sound or sound is too low at maximum volume.	<ul style="list-style-type: none">Set the Speaker Select option to TV speaker in the sound menu.Make sure audio cables from an external device are connected to correct audio input jacks on the TV.Check connected device's audio output option. (ex: You may need to change your cable box' audio option to HDMI when you have HDMI connected to your TV)If you are using a DVI to HDMI cable, a separate audio cable is required.Deactivate SRS function if you are setting the volume over 30 value.Remove plug from headphone jack. (if available on your TV)
Noise from speaker.	<ul style="list-style-type: none">Check cable connections. Make sure a video cable is not connected to an audio input.For Antenna/Cable connection, check signal strength. Low signal level may cause sound distortion.

Remote Control


- [2] You can use the remote control up to a distance of about 23 feet from the TV.
[2] The performance of the remote control may be affected by bright light.
[2] The product colour and shape may vary depending on the model.

- 1 POWER** : Television Standby button.
- 2 NUMERIC BUTTONS** : Press to change the channel.
- 3 FAV.CH** : Used to display Favourites Channel Lists on the screen.
- 4 —▲+ / —▼+** : Press to increase or decrease the volume.
- 5 SOURCE** : Press to display and select the available video sources.
- 6 INFO** : Press to display information on the TV screen.
- 7 TOOLS** : Use to quickly select frequently used functions.
- 8 CH LIST** : Displays the Channel List on screen.
- 9 COLOURS BUTTONS** : Use these buttons in the **Channel List** menus etc.
- 11 TV** : Selects the TV mode directly.
- 12 PRE-CH** : Enables you to return to the previous channel you were watching.
- 13 MUTE/κ** : Press to temporarily cut off the sound.
- 14 P / Δ / P / ∇** : Press to change channels.
- 15 MENU** : Displays the main on-screen menu
- 16 GUIDE** : Electronic Programme Guide (EPG) display
- 17 RETURN** : Returns to the previous menu
- 18 UP / Δ / DOWN / ∇ / LEFT / ◀ / RIGHT / ▶ / ENTER** : Use to select on-screen menu items and change menu values.
- 19 EXIT** : Press to exit the menu.
- 20 SUBT.** : Digital subtitle display
- 21 AD** : Audio Description selection.
- Teletext Functions**
- 5** [] : Teletext mode selection (LIST / FLOP)
- 6** [E] : Teletext reveal
- 7** [E3] : Teletext size selection on screen.
- 8** [E9] : Teletext store
- 9** [E] : Fastest topic selection
- 10** [E/E] : Alternately select Teletext, Double, or Mix.
- 11** [] : Exit from the Teletext display
- 12** [E9] : Teletext sub page
- 13** [E3] : Teletext next page
- 14** [E1] : Teletext previous page
- 15** [E1] : Teletext index
- 16** [E3] : Teletext hold
- 19** [E3] : Teletext cancel



Installing Batteries in the Remote Control

- Lift the cover at the back of the remote control upward as shown in the figure.
- Install two AAA size batteries.
[2] Make sure to match the '+' and '-' ends of the batteries with the diagram inside the compartment.
- Replace the cover.
[2] Remove the batteries and store them in a cool, dry place if you won't be using the remote control for a long time.
[2] If the remote control doesn't work, check the following:
 - Is the TV power on?
 - Are the plus and minus ends of the batteries reversed?
 - Are the batteries drained?
 - Is there a power outage or is the power cord unplugged?
 - Is there a special fluorescent light or neon sign nearby?



OPERATION

Viewing the menus

Before using the TV, follow the steps below to learn how to navigate the menu in order to select and adjust different functions.

1. Press the **MENU** button.
The main menu is displayed on the screen. Its left side has icons: **Picture, Sound, Channel, Setup, Input, Application, Support**.
2. Press the **▲** or **▼** button to access the icon's sub-menu.
3. Press the **▲** or **▼** button to move to items in the menu.
Press the **ENTER** button to enter items in the menu.
4. Press the **▲/▼/▲/▼** button to change the selected items.
 Press the **RETURN** button to return to the previous menu.
5. Press the **EXIT** button to exit from the menu.


Using the remote control buttons

Button	Operations	Button	Operations
MENU	Display the main on-screen menu.	▲/▼/▲/▼	Move the cursor and select an item.
RETURN	Return to the previous menu.	ENTER	Select the currently selected item.
EXIT	Exit the on-screen menu.		Confirm the setting.

Example: Setting the TV's Brightness in the Picture Menu

- **Adjusting the Brightness to 80**

1. Press the **MENU** button to display the menu.
2. Press the **ENTER** button to select **Picture**.




3. Press the **▲** or **▼** button to select **Brightness**.



4. Press the **ENTER** button.



5. Press the **▲** or **▼** button until the brightness becomes 80.



6. Press the **ENTER** button.
- Press the **EXIT** button to exit from the menu.






Securing the TV to the Wall



Caution: Pulling, pushing, or climbing on the TV may cause the TV to fall. In particular, ensure your children do not hang over or destabilize the TV, doing so may cause the TV to tip over, causing serious injuries or death. Follow all safety precautions provided on the included Safety Flyer. For added stability, install the anti-fall device for safety purposes, as follows.

- **To avoid the TV from falling:**


1. Put the screws into the clamps and firmly fasten them onto the wall. Confirm that the screws have been firmly installed onto the wall.
 You may need additional material such as an anchor depending on the type of wall.
 Since the necessary clamps, screws, and string are not supplied, please purchase these additionally.
2. Remove the screws from the centre back of the TV, put the screws into the clamps, and then fasten the screws onto the TV again.
 Screws may not be supplied with the product. In this case, please purchase the screws of the following specifications.
 Screw Specifications
– For a 17 ~ 29 inch LCD TV: M4 X L15
– For a 32 ~ 40 inch LCD TV: M6 X L15
3. Connect the clamps fixed onto the TV and the clamps fixed onto the wall with a strong string and then tie the string tightly.
 Install the TV near to the wall so that it does not fall backwards.
 It is safe to connect the string so that the clamps fixed on the wall are equal to or lower than the clamps fixed on the TV.
 Untie the string before moving the TV.
4. Verify all connections are properly secured. Periodically check connections for any sign of fatigue for failure. If you have any doubt about the security of your connections, contact a professional installer.



Using the Anti-Theft Kensington Lock

The Kensington Lock is a device used to physically fix the system when using it in a public place. The appearance and locking method may differ from the illustration depending on the manufacturer. Refer to the manual provided with the Kensington Lock for proper use. The locking device has to be purchased separately. The location of the Kensington Lock may be different depending on its model.

1. Insert the locking device into the Kensington slot on the LCD TV (❶) and turn it in the locking direction (❷).
2. Connect the Kensington Lock cable (❸).
3. Fix the Kensington Lock to a desk or a heavy stationary object.




Securing the Installation Space

Keep the required distances between the product and other objects (e.g. walls) to ensure proper ventilation.


Failing to do so may result in fire or a problem with the product due to an increase in the internal temperature of the product. Install the product so the required distances shown in the figure are kept.

- ❷ When using a stand or wall-mount, use parts provided by Samsung Electronics only.
- If you use parts provided by another manufacturer, it may result in a problem with the product or an injury due to the product falling.
- If you use parts provided by another manufacturer, it may result in a problem with the product or fire due to an increase in the internal temperature of the product due to poor ventilation.
- ❷ The appearance may differ depending on the product.

When installing the product with a stand



When installing the product with a wall-mount



Placing Your Television in Standby Mode

Your set can be placed in standby mode in order to reduce the power consumption. The standby mode can be useful when you wish to interrupt viewing temporarily (during a meal, for example).

1. Press the **POWER** button on the remote control.
2. The screen is turned off and a standby indicator appears on your set.
2. To switch your set back on, simply press the **POWER** button again.
- ❷ Do not leave your set in standby mode for long periods of time (when you are away on holiday, for example). It is best to unplug the set from the mains and aerial.

Plug & Play Feature

When the TV is initially powered on, basic settings proceed automatically and subsequently.

1. Press the **POWER** button on the remote control. The message **You can set the menu language** is displayed.
2. Select the appropriate language by pressing the **▲** or **▼** button. Press the **ENTER** button to confirm your choice.
3. Press the **◀** or **▶** button to select **Store Demo** or **Home Use**, then the **ENTER** button.

- ❷ We recommend setting the TV to **Home Use** mode for the best picture in your home environment.
- ❷ **Store Demo** mode is only intended for use in retail environments.
- ❷ If the unit is accidentally set to **Store Demo** mode and you want to return to **Home Use (Standard)**: Press the Volume button on the TV. When the volume OSD is displayed, press and hold the **MENU** button on the TV for 5 seconds.

4. Press the **ENTER** button. Select the appropriate country by pressing the **▲** or **▼** button. Press the **ENTER** button to confirm your choice.
5. Press the **▲** or **▼** button to select **Air** or **Cable**, then press the **ENTER** button.

- ❷ **Air**: Air antenna signal.
- Cable**: Cable antenna signal.

6. Press the **▲** or **▼** button to select the channel source to memorize. Press the **ENTER** button to select **Start**.

❷ **Digital & Analogue**: Digital and Analogue channels.

❷ **Digital**: Digital channels.

❷ **Analogue**: Analogue channels.

❷ When setting the antenna source to **Cable**, a step appears allowing you to set a value for the digital channel search. For more information, refer to **Channel** → **Auto Store**.

❷ The channel search will start and end automatically.

❷ Press the **ENTER** button at any time to interrupt the memorization process.

❷ After all the available channels are stored, the message **Set the Clock Mode** is displayed.

7. Press the **ENTER** button. Press the **▲** or **▼** button to select **Auto**, then Press the **ENTER** button.

❷ If you select **Manual**, **Set current date and time** is displayed.

❷ If you have received a digital signal, the time will be set automatically. If not, select **Manual** to set the clock. (refer to page 19)

8. The connection method to provide the best quality HD is offered. After confirming the method, press the **ENTER** button.
9. The message **Enjoy your TV!** is displayed. When you have finished, press the **ENTER** button.


If you want to reset this feature...

1. Press the **MENU** button to display the menu. Press the **▲** or **▼** button to select **Setup**, then press the **ENTER** button.
2. Press the **ENTER** button again to select **Plug & Play**.
3. Enter your 4 digit PIN number. The default PIN number of a new TV set is **0-0-0-0**.
- ❷ If you want to change PIN number, use the **Change PIN** function. (refer to page 21)
- ❷ The **Plug & Play** feature is only available in the TV mode.




Viewing the Display


The display identifies the current channel and the status of certain audio-video settings.

 Press the **INFO** button to viewing the information.

Press the **INFO** button on the remote control. The TV will display the channel, the type of sound, and the status of certain picture and sound settings.

- **▲ / ▼** : You can view other channels' information. If you want to move to the currently selected channel, press **ENTER**  button.
- **◀ / ▶** : You can view the desired program's information at the current channel.

 Press the **INFO** button once more or wait approximately 10 seconds and the display disappears automatically.



CHANNEL CONTROL

Configuring the Channel Menu

Country

 The PIN number input screen appears. Enter your 4 digit PIN number.

Analogue Channel

You can change the country for analogue channels.

Digital Channel

You can change the country for digital channels.

Auto Store

You can scan for the frequency ranges available to you (and availability depends on your country). Automatically allocated programme numbers may not correspond to actual or desired programme numbers.

 If a channel is locked using the **Child Lock** function, the PIN input window appears.

Air / Cable

Antenna source to memorize

- **Digital & Analogue**: Digital and Analogue channels.

- **Digital**: Digital channels.

- **Analogue**: Analogue channels.

When selecting 'Cable → Digital & Analogue' or 'Cable → Digital'

Provide a value to scan for cable channels.

- **Search Mode** → **Full / Network / Quick**


Quick

– **Network ID**: Displays the network identification code.

– **Frequency**: Displays the frequency for the channel. (Differs in each country)

– **Modulation**: Displays available modulation values.

– **Symbol Rate**: Displays available symbol rates.

 Scans for all channels with active broadcast stations and stores them in the TV's memory.

 If you want to stop Auto Store, press the **ENTER**  button.

The **Stop Auto Store?** message will be displayed.


Select **Yes** by pressing the **◀** or **▶** button, then press the **ENTER**  button.



 Teletext information is often divided between several pages displayed in sequence, which can be accessed by:

- Entering the page number
- Selecting a title in a list
- Selecting a coloured heading (FASTEXT system)

 Teletext level supported by the TV is version 2.5 which is capable of displaying additional graphics or text.

 Depending upon the transmission, blank side panels can occur when displaying Teletext.

 In these cases, additional graphics or text is not transmitted.


 Older TVs which do not support version 2.5 are not capable of displaying any additional graphics or text, regardless of the Teletext transmission.

 Press the **TV** button to exit from the Teletext display.

 Teletext 16:9, picture is 16:9



Installing the Stand



 **Presat**: Place the Guide Stand and Cover Neck onto the stand and fasten it using the screws. Applicable to 32inch models only.



1. Attach your LCD TV to the stand.

 Two or more people should carry the TV.

 Make sure to distinguish between the front and back of the stand when assembling them.

 To make sure the TV is installed on the stand at a proper level, do not apply excess downward pressure to the upper left or right sides of the TV.

-  Fasten two screws at position **1** and then fasten two screw at position **2**.
-  Stand the product up and fasten the screws. If you fasten the screws with the LCD TV placed down, it may lean to one side.




Installing the Wall Mount Kit

Wall mount items (sold separately) allow you to mount the TV on the wall.

For detailed information on installing the wall mount, see the instructions provided with the Wall Mount items. Contact a technician for assistance when installing the wall mounted bracket.

Samsung Electronics is not responsible for any damage to the product or injury to yourself or others if you elect to install the TV on your own.

 Do not install your Wall Mount Kit while your TV is turned on. It may result in personal injury due to electric shock.




RECOMMENDATIONS FOR USE

Teletext Feature

Most television stations provide written information services via Teletext. The index page of the Teletext service gives you information on how to use the service. In addition, you can select various options to suit your requirements by using the remote control buttons.


- For Teletext information to be displayed correctly, channel reception must be stable. Otherwise, information may be missing or some pages may not be displayed.
- You can change Teletext pages by pressing the numeric buttons on the remote control.

- **1 (mode)**
Press to select the Teletext mode (LIST/FLOF). If you press it in the LIST mode, it switches into the List save mode. In the List save mode, you can save Teletext page info list using the **60 (store)** button.
- **2 (reveal)**
Used to display the hidden text (answers to quiz games, for example), to display normal screen, press it again.
- **3 (size)**
Press to display the double-size letters in the upper half of the screen. For lower half of the screen, press it again. To display normal screen, press it once again.
- **4 (store)**
Used to store the Teletext pages.
- **5 Colour buttons (red/green/yellow/blue)**
If the FASTEXT system is used by a broadcasting company, the different topics covered on a Teletext page are colour-coded and can be selected by pressing the coloured buttons. Press one of them corresponding to the required. The page is displayed with other coloured information that can be selected in the same way. To display the previous or next page, press the corresponding coloured button.
- **6 (Teletext on/mix)**
Press to activate Teletext mode after selecting the channel providing the Teletext service. Press it twice to overlap the Teletext with the current broadcasting screen.
- **7 (exit)**
Exit from the Teletext display.
- **8 (sub-page)**
Used to display the available sub-page.
- **9 (page up)**
Used to display the next Teletext page.
- **10 (page down)**
Used to display the previous Teletext page.
- **11 (hold)**
Used to hold the display on a given page if the selected page is linked with several secondary pages which follow on automatically. To resume, press it again.
- **12 (index)**
Used to display the index (contents) page at any time while you are viewing Teletext.
- **13 (cancel)**
Used to display the broadcast when searching for a page.



The Teletext pages are organized according to six categories:

Part	Contents
A	Selected page number.
B	Broadcasting channel identity.
C	Current page number or search indications.
D	Date and time.
E	Text.
F	Status information. FASTEXT information.



Manual Store

- Scans for a channel manually and stores it in the TV's memory.
- If a channel is locked using the **Child Lock** function, the PIN input window appears.

Digital Channel

Manual store for digital channels.

- **Digital Channel** is only available in DTV mode.
- **Channel:** Set the Channel number using the **▲**, **▼** or number **(0-9)** buttons.
- **Frequency:** Set the frequency using the number buttons.
- **Bandwidth:** Set the bandwidth using the **▲**, **▼** or number **(0-9)** buttons.
- When it has finished, channels are updated in the channel list.

Analogue Channel

Manual store for analogue channel.

- **Programme** (Programme number to be assigned to a channel). Sets the programme number using the **▲**, **▼** or number **(0-9)** buttons.
- **Colour System** → **BG / DK / I / L**. Sets the colour system value using the **▲** or **▼** button.
- **Sound System** → **BG / DK / I / L**. Sets the sound system value using the **▲** or **▼** button.
- **Channel** (When you know the number of the channel to be stored): Press the **▲** or **▼** button to select **C** (Air channel) or **S** (Cable channel). Press the **►** button, then press the **▲**, **▼** or number **(0-9)** buttons to select the required number.
- You can also select the channel number directly by pressing the number **(0-9)** buttons.
- If there is abnormal sound or no sound, reset the sound standard required.
- **Search** (When you do not know the channel numbers): Press the **▲** or **▼** button to start the search. The tuner scans the frequency range until the first channel or the channel that you selected is received on the screen.
- **Store** (When you store the channel and associated programme number): Set to **OK** by pressing the **ENTER** **⏏** button.
- **Channel mode**
 - **P** (Programme mode): When completing tuning, the broadcasting stations in your area have been assigned to position numbers from P00 to P99. You can select a channel by entering the position number in this mode.
 - **C** (Air channel mode): You can select a channel by entering the assigned number to each air broadcasting station in this mode.
 - **S** (Cable channel mode): You can select a channel by entering the assigned number for each cable channel in this mode.

Cable Search Option (depending on the country)

Sets additional search options such as the frequency and symbol rate for cable network searches.

- **Frequency (Start ~ Stop):** Displays the frequency for the channel.
- **Modulation:** Displays available modulation values.
- **Symbol Rate:** Displays available symbol rates.

Now & Next Guide / Full Guide

The EPG (Electronic Programme Guide) information is provided by the broadcasters. Programme entries may appear blank or out of date as a result of the information broadcast on a given channel. The display will dynamically update as soon as new information becomes available.

- For detailed procedures on using **Now & Next Guide** and **Full Guide**, refer to the descriptions on page 10.

- You can also display the guide menu simply by pressing the **GUIDE** button. (To configure the **Default Guide**, refer to the descriptions.)

Now & Next Guide

For the six channels indicated in the left-hand column, displays the Current programme and the Next programme information.

Full Guide

Displays the programme information as time ordered One hour segments. Two hours of programme information is displayed which may be scrolled forwards or backwards in time.

❑ **Default Guide → Now & Next Guide / Full Guide**

You can decide whether to display either the **Now & Next Guide** or the **Full Guide** when the **GUIDE** button on the remote control is pressed.

❑ **Channel List**

For detailed procedures on using the **Channel List**, refer to the 'Managing Channels' instructions.

⑦ You can select these options by simply pressing the **CH LIST** button on the remote control.

❑ **Channel Mode**

When press the **P** **✓/∧** button, Channels will be switched within the selected channel list.

■ **Added Ch.**

Channels will be switched within the memorized channel list.

■ **Favourite Ch.**

Channels will be switched within the favourite channel list.

❑ **Fine Tune**

If the reception is clear, you do not have to fine tune the channel, as this is done automatically during the search and store operation. If the signal is weak or distorted, you may have to fine tune the channel manually.

⑦ Fine tuned channels that have been saved are marked with an asterisk, "*" on the right-hand side of the channel number in the channel banner.

⑦ To reset the fine-tuning, select **Reset** by pressing the **▲** or **▼** button and then press the **ENTER** **↵** button.

⑦ Only Analogue TV channels can be fine tuned.

Using the Now & Next Guide / Full Guide



To...	Then...
Watch a programme in the EPG list	Select a programme by pressing the ▲ , ▼ , ◀ , ▶ button.
Exit the guide	Press the blue button
If the next programme is selected, it is scheduled with the clock icon displayed. If the ENTER ↵ button is pressed again, press the ◀ , ▶ button to select Cancel Schedules , the scheduling is cancelled with the clock icon gone.	Select a programme of your choice by pressing the ▲ , ▼ , ◀ , ▶ button.
View programme information	Then press the INFO button when the programme of your choice is highlighted. The programme title is on the upper part of the screen centre.
Please click on INFO button for detailed information. Channel Number, Running Time, Status Bar, Parental Level, Video Quality Information (HD / SD), Sound Modes, Subtitle or Teletext, languages of Subtitle or Teletext and brief summary of the highlighted programme are included on the detailed information. "... will be appeared if the summary is long.	
Toggle between the Now & Next Guide and Full Guide	
In Full Guide	
Scrolls backwards quickly (24 hours).	Press the green button repeatedly.
Scrolls forwards quickly (24 hours).	Press the yellow button repeatedly.

❑ **Software Upgrade**

To keep your product up-to-date with new Digital Television features then software upgrades are periodically broadcast as part of the normal Television signal. It will automatically detect these signals and display the software upgrade banner. You are given the option to install the upgrade.

■ **BY USB**

Insert a USB drive containing the firmware upgrade into TV. Please be careful to not disconnect the power or remove the USB drive while upgrades are being applied. The TV will turn off and turn on automatically after completing the firmware upgrade. Please check the firmware version after the update is completed. When software is upgraded, video and audio settings you have made will return to their default (factory) settings.

We recommend you write down your settings so that you can easily reset them after the upgrade.

■ **BY Channel**

Upgrades the software using the broadcasting signal.

⑦ If the function is selected during the software transmission period, this function searches for available software and downloads the software.

⑦ The time required to download the software is determined by the signal status.

■ **Standby Mode Upgrade**

To continue software upgrade with master power on. Select On by pressing the **▲** or **▼** button. 45 minutes after entering standby mode, a manual upgrade is automatically conducted. Since the power of the unit is turned on internally, the screen may be on slightly for the LCD product. This phenomenon may continue for more than 1 hour until the software upgrade is completed.

■ **Alternative Software**

To display the software version information.


❑ **HD Connection Guide**

This menu presents the connection method that provides the optimal quality for the HD TV.

Refer to this information when connecting external devices to the TV.

❑ **Contact Samsung**

View this information when your TV does not work properly or when you want to upgrade the software. You can view the information regarding the call centre, product and software file download method.



Configuring the Input Menu

Source List

Use to select TV or other external input sources such as DVD / Blu-ray players / Satellite receivers (Set-Top Box) connected to the TV. Use to select the input source of your choice.

 Press the **SOURCE** button on the remote control to view an external signal source. TV mode can be selected by pressing the TV button.

TV / Ext. / AV / Component / PC / HDMI / DVI / HDMI2 / HDMI3

 You can choose only those external devices that are connected to the TV. In the **Source List**, connected inputs will be highlighted and sorted to the top. Inputs that are not connected will be sorted to the bottom.

 Ext. and PC always stay activated.

 **TOOLS (Tools):** Displays the **Edit Name** and **Information** menus.



Edit Name

Name the device connected to the input jacks to make your input source selection easier.

VCR / DVD / Cable STB / Satellite STB / PVR STB / AV Receiver / Game / Camcorder / PC / DVI / DVI PC / TV / IPTV / Blu-ray / HD DVD / DMAP

 When connecting an HDMI/DVI cable to the **HDMI IN (DVI)** port, you should set the **HDMI/DVI** mode to **DVI** or **DVI PC** in the **Edit Name** of the **Input** mode. In this case, a separate sound connection is required.

Configuring the Support Menu

Self Diagnosis

Picture Test



If you think you have a picture problem, perform the picture test. Check the colour pattern on the screen to see if the problem still exists.

- **Yes:** If the test pattern does not appear or there is noise in the test pattern, select **Yes**. There may be a problem with the TV. Contact Samsung's call centre for assistance.
- **No:** If the test pattern is properly displayed, select **No**. There may be a problem with your external equipment. Please check your connections. If the problem still persists, refer to the external device's user manual.



Sound Test

If you think you have a sound problem, please perform the sound test. You can check the sound by playing a built-in melody sound through the TV. Does the problem still exist with this sound test? appears on the screen.

-  If you hear no sound from the TV's speakers, before performing the sound test, make sure **Speaker Select** is set to **TV speaker** in the Sound menu.
-  The melody will be heard during the test even if **Speaker Select** is set to **External Speaker** or the sound is muted by pressing the **MUTE** button.
- **Yes:** If during the sound test you can hear sound only from one speaker or not at all, select **Yes**. There may be a problem with the TV. Contact Samsung's call centre for assistance.
- **No:** If you can hear sound from the speakers, select **No**. There may be a problem with your external equipment. Please check your connections. If the problem still persists, refer to the external device's user manual.

Signal Information (digital channels only)

Unlike analogue channels, which can vary in reception quality from 'snowy' to clear, digital (HDTV) channels have either perfect reception quality or you will not receive them at all. So, unlike analogue channels, you cannot fine tune a digital channel. You can, however, adjust your antenna to improve the reception of available digital channels.

 If the signal strength meter indicates that the signal is weak, physically adjust your antenna to increase the signal strength. Continue to adjust the antenna until you find the best position with the strongest signal.

Managing Channels

Using this menu, you can Add / Delete or set Favourite channels and use the programme guide for digital broadcasts.

All Channels

Shows all currently available channels.

Added Channels

Shows all added channels.


Favourites

Shows all favourite channels.

 To select the Favourites channels you have set up, press the **FAV CH** button on the remote control.

Programmed







Shows all current reserved programmes.

 Select a channel in the **All Channels**, **Added Channels** or **Favourites** screen by pressing the **▲** / **▼** buttons, and pressing the **ENTER** button. Then you can watch the selected channel.



 Using the **Colour buttons** with the **Channel List**

- **Red (Channel Type):** Toggle between your **TV**, **Radio**, **Data** / **Other** and **All**.
- **Green (Zoom):** Enlarges or shrinks a channel number.
- **Yellow (Select):** Selects multiple channel lists. You can perform the add / delete, add to Favourites / delete from Favourites, or lock / unlock function for multiple channels at the same time. Select the required channels and press the yellow button to set all the selected channels at the same time. The **✓** mark appears to the left of the selected channels.
- **TOOLS (Tools):** Displays the **Delete** (or **Add**), **Add to Favourite** (or **Delete from Favourite**), **Lock** (or **Unlock**), **Timer Viewing**, **Edit Channel Name**, **Sort**, **Edit Channel Number**, **Select All** (or **Deselect All**), **Auto Store** menu. (The Options menu may differ depending on the situation.)

Channel Status Display Icons


-  : An analogue channel.
-  : A channel selected by pressing the yellow button.
-  : A channel set as a Favourite.
-  : A programme currently being broadcast.
-  : A locked channel.
-  : A reserved programme

Channel List Option Menu (in All Channels / Added Channels / Favourites)

-  Press the **TOOLS** button to use the option menu.
-  Option menu items may differ depending on the channel status.




Add / Delete


You can delete or add a channel to display the channels you want.

-  All deleted channels will be shown on **All Channels** menu.
-  A gray-coloured channel indicates the channel has been deleted.
-  The **Add** menu only appears for deleted channels.
-  You can also delete a channel from the **Added Channels** or **Favourites** menu in the same manner.

Add to Favourite / Delete from Favourite

You can set channels you watch frequently as Favourites.

-  Press the **TOOLS** button to display the **Tools** menu. You can also set the add to (or delete from) Favourite by selecting **Tools** → **Add to Favourite** (or **Delete from Favourite**).
-  The **♥** symbol will be displayed and the channel will be set as a favourite.
-  All favourite channels will be shown on **Favourites** menu.



☐ Broadcast

■ Subtitle

You can activate and deactivate the subtitles. Use this menu to set the Subtitle Mode. **Normal** under the menu is the basic subtitle and **Hard of hearing** is the subtitle for a hearing-impaired person.

- **Subtitle → Off / On** : Switches subtitles on or off.
- **Mode → Normal / Hard of hearing** : Sets the subtitle mode.
- **Subtitle Language** : Set the subtitle language.

☒ If the programme you are watching does not support the **Hard of hearing** function, **Normal** automatically activates even though **Hard of hearing** mode is selected.

☒ English is the default in cases where the selected language is unavailable in the broadcast.

☒ You can select these options simply by pressing the **SUBT** button on the remote control.

■ Digital Text → Disable / Enable (UK only)

If the programme is broadcast with digital text, this feature is enabled.

☒ **MHEG** (Multimedia and Hypermedia Information Coding Experts Group)

An international standard for data encoding systems used in multimedia and hypermedia. This is at a higher level than the MPEG system which includes data-linking hypermedia such as still images, character service, animation, graphic and video files as well as multimedia data. MHEG is user runtime interaction technology and is being applied to various fields including VOD (Video-On-Demand), ITV (Interactive TV), EC (Electronic Commerce), tele-education, tele-conferencing, digital libraries and network games.

■ Teletext Language

You can set the Teletext language by selecting the language type.

☒ English is the default in cases where the selected language is unavailable in the broadcast.

■ Preference

- **Primary Audio Language / Secondary Audio Language / Primary Subtitle Language / Secondary Subtitle Language / Primary Teletext Language / Secondary Teletext Language**

Using this feature, users can select one of the languages. The language selected here is the default when the user selects a channel.

If you change the language setting, the Subtitle Language, Audio Language, and the Teletext Language of the Language menu are automatically changed to the selected language.

The Subtitle Language, Audio Language, and the Teletext Language of the Language menu show a list of languages supported by the current channel and the selection is highlighted. If you change this language setting, the new selection is only valid for the current channel. The changed setting does not change the setting of the Primary Subtitle Language, Primary Audio Language, or the Primary Teletext Language of the Preference menu.

■ Common Interface

● CI Menu

This enables the user to select from the CAM-provided menu. Select the CI Menu based on the menu PC Card.

● Application Info.

This contains information on CAM inserted in the CI slot and displays it.

☒ The Application Info inserting is about the 'CI CARD'. You can install the CAM anytime whether the TV is ON or OFF.

1. Purchase the CI CAM module by visiting your nearest dealer or by phone.
2. Insert the 'CI CARD' into the CAM in the direction of the arrow until it fits.
3. Insert the CAM with the 'CI CARD' installed into the common interface slot.
(Insert the CAM in the direction of the arrow, right up to the end so that it is parallel with the slot.)
4. Check if you can see a picture on a scrambled signal channel.

☒ CAM is not supported in some countries and regions, check with your authorized dealer.

PICTURE CONTROL

Configuring the Picture Menu

☐ Mode

You can select the type of picture which best corresponds to your viewing requirements.

☒ Press the **TOOLS** button to display the **Tools** menu. You can also set the picture mode by selecting **Tools → Picture Mode**.

■ Dynamic

Selects the picture for high-definition in a bright room.

■ Standard

Selects the picture for the optimum display in a normal environment.

■ Movie

Selects the picture for viewing movies in a dark room.

☐ Backlight / Contrast / Brightness / Sharpness / Colour / Tint (G/R)

Your television has several setting options that allow you to control the picture quality.

- **Backlight**: Adjusts the brightness of LCD back light.
- **Contrast**: Adjusts the contrast level of the picture.
- **Brightness**: Adjusts the brightness level of the picture
- **Sharpness**: Adjusts the edge definition of the picture.
- **Colour**: Adjusts colour saturation of the picture.
- **Tint (G/R)**: Adjusts the colour tint of the picture.

☒ Select a picture mode to be adjusted first. The adjusted values are saved for each picture mode.
☒ When you make changes to **Backlight**, **Contrast**, **Brightness**, **Sharpness**, **Colour** or **Tint (G/R)**, the OSD will be adjusted accordingly.

☒ In analogue TV, **Ext. AV** modes of the PAL system, you cannot use the **Tint (G/R)** Function.

☒ In PC mode, you can only make changes to **Backlight**, **Contrast** and **Brightness**.

☒ Settings can be adjusted and stored for each external device you have connected to an input of the TV.

☒ The energy consumed during use can be significantly reduced if the brightness level of the picture is reduced, which will reduce the overall running cost.

☐ Advanced Settings

Samsung's new TVs allow you to make even more precise picture settings than previous models. See below to adjust detailed picture settings.

☒ **Advanced Settings** is available in **Standard** or **Movie** mode.

☒ In PC mode, you can only make changes to **Gamma** and **White Balance** from among the **Advanced Settings** items.

■ Black Tone → Off / Dark / Darker / Darkest

You can select the black level on the screen to adjust the screen depth.

■ Dynamic Contrast → Off / Low / Medium / High

You can adjust the screen contrast so that the optimal contrast is provided.

■ Gamma

You can adjust the Primary Colour (Red, Green, Blue) Intensity.

■ Colour Space

Colour Space is a colour matrix composed of red, green and blue colours. Select your favourite Colour Space to experience the most natural colour.

- **Native**: Native Colour Space offers deep and rich colour tone.
- **Auto**: Auto Colour Space automatically adjusts to the most natural colour tone based on programme sources.



SETUP

Configuring the Setup Menu

Menu Language

You can set the menu language.

Time

Clock

Setting the clock is necessary in order to use the various timer features of the TV.

- **Time**
 - The current time will appear every time you press the **INFO** button.
- If you disconnect the power cord, you have to set the clock again.

Clock Mode

You can set up the current time manually or automatically.

- **Auto**: Set the current time automatically using the time from the digital broadcast.
 - **Manual**: Set the current time to a manually specified time.
- Depending on the broadcast station and signal, the auto time may not be set correctly. If this occurs, set the time manually.

- **Clock Set**
 - The Antenna or cable must be connected in order to set the time automatically.

Clock Set

You can set the current time manually.

- **Set up** this item when you have set **Clock Mode** to **Manual**.

You can set the day, month, year, hour and minute directly by pressing the number buttons on the remote control.

Sleep Timer → Off / 30 min / 60 min / 90 min / 120 min / 150 min / 180 min

The sleep timer automatically shuts off the TV after a preset time (30, 60, 90, 120, 150 and 180 minutes).

- The TV automatically switches to standby mode when the timer reaches 0.

- To cancel the **Sleep Timer** function, select **Off**.

Press the **TOOLS** button to display the **Tools** menu. You can also set the sleep timer by selecting **Tools** → **Sleep Timer**.

Timer 1 / Timer 2 / Timer 3

Three different on / off timer settings can be made. You must set the clock first.

- **On Time**: Set the hour, minute, and activate / inactivate. (To activate the timer with the setting you've chosen, set to **Activate**.)
- **Off Time**: Set the hour, minute, and activate / inactivate. (To activate the timer with the setting you've chosen, set to **Activate**.)
- **Volume**: Select the desired turn on volume level.
- **Antenna**: Select **Air** or **Cable**.
- **Channel**: Select the desired channel.

- **Repeat**: Select **Once**, **Everyday**, **Mon-Fri**, **Mon-Sat**, **Sat-Sun** or **Manual**.

- When **Manual** is selected, press the **►** button to select the desired day of the week. Press the **ENTER** button over the desired day and the **✓** mark will appear.

- You can set the hour, minute and channel by pressing the number buttons on the remote control.

Auto Power Off

When you set the timer On, the television will eventually turn off, if no controls are operated for 3 hours after the TV was turned on by the timer. This function is only available in timer On mode and prevents overheating, which may occur if a TV is on for too long time.

White Balance

You can adjust the colour temperature for more natural picture colours.

- **R-Offset / G-Offset / B-Offset / R-Gain / B-Gain**: You can adjust the Colour temperature in the light areas by changing the values of R, G, B. Recommended for advanced users only.
- **Reset**: The previously adjusted white balance will be reset to the factory defaults.

Flesh Tone

You can emphasize the pink 'flesh tone' in the picture.

- Changing the adjustment value will refresh the adjusted screen.

Edge Enhancement → Off / On

You can emphasize object boundaries in the picture.

Picture Options

- In PC mode, you can only make changes to the **Colour Tone** and **Size** from among the items in **Picture Options**.

Colour Tone → Cool / Normal / Warm1 / Warm2

You can select the most comfortable colour tone to your eyes.

- Settings can be adjusted and stored for each external device you have connected to an input of the TV.
- **Warm1** or **Warm2** is only activated when the picture mode is **Movie**.

Size

You can select the picture size which best corresponds to your viewing requirements.

- Press the **TOOLS** button to display the **Tools** menu. You can also set the size by selecting **Tools** → **Picture Size**.

- **Auto Wide**: Automatically adjusts the picture size to the **16:9** aspect ratio.
- **16:9**: Adjusts the picture size to 16:9 appropriate for DVDs or wide broadcasting.
- **Wide Zoom**: Magnify the size of the picture more than 4:3.
- **Zoom**: Magnifies the 16:9 wide picture (in the vertical direction) to fit the screen size.
- **4:3**: This is the default setting for a video movie or normal broadcasting.
- **Screen Fit**: Use the function to see the full image without any cut-off when HDMI (720p / 1080i) or Component (1080i) signals are input.

- Depending on the input source, the picture size options may vary.

- The items available may differ depending on the selected mode.

- In PC Mode, only **16:9** and **4:3** mode can be adjusted.

- Settings can be adjusted and stored for each external device you have connected to an input of the TV.

- Temporary image retention may occur when viewing a static image on the set for more than two hours.

- **Wide Zoom**: Press the **►** button to Select **Position**, then press the **ENTER** button. Press the **▲** or **▼** button to move the picture up / down. Then press the **ENTER** button.

- **Zoom**: Press the **►** button to Select **Position**, then press the **ENTER** button. Press the **▲** or **▼** button to move the picture up and down. Then press the **ENTER** button. Press the **►** button to Select **Size**, then press the **ENTER** button. Press the **▲** or **▼** button to magnify or reduce the picture size in the vertical direction. Then press the **ENTER** button.

- After selecting **Screen Fit** in HDMI (1080i) or Component (1080i) mode: Select **Position** by pressing the **▲** or **►** button. Use the **▲**, **▼**, **◀** or **►** button to move the picture.

- **Reset**: Press the **◀** or **►** button to select **Reset**, then press the **ENTER** button. You can initialize the setting.

- If you use the **Screen Fit** function with HDMI 720p input, 1 line will be cut at the top, bottom, left and right as in the Overscan function.

Screen Mode → 16:9 / Wide Zoom / Zoom / 4:3

When setting the picture size to **Auto Wide** in a 16:9 wide TV, you can determine the picture size you want to see the 4:3 WSS (Wide Screen Service) image or nothing. Each individual European country requires different picture size so this function is intended for users to select it.

- **16:9**: Sets the picture to 16:9 wide mode.
- **Wide Zoom**: Magnify the size of the picture more than 4:3.
- **Zoom**: Magnify the size of the picture vertically on screen.
- **4:3**: Sets the picture to 4:3 normal mode.
- This function is available in **Auto Wide** mode.
- This function is not available in **PC**, **Component** or **HDMI** mode.



☐ **Audio Description (digital channels only)**

This is an auxiliary audio function that provides an additional audio track for visually challenged persons. This function handles the Audio Stream for the AD (Audio Description), when it is sent along with the Main audio from the broadcaster. Users can turn the Audio Description On or Off and control the volume.

Press the **AD** button on the remote control to select **Off** or **On**.

■ **Audio Description → Off / On**

Turn the audio description function on or off.

■ **Volume**

You can adjust the audio description volume.

Volume is active when **Audio Description** is set to **On**.

☐ **Auto Volume → Off / On**

Each broadcasting station has its own signal conditions, and so it is not easy to adjust the volume every time the channel is changed. This feature lets you automatically adjust the volume of the desired channel by lowering the sound output when the modulation signal is high or by raising the sound output when the modulation signal is low.

☐ **Speaker Select → External Speaker / TV Speaker**

If you want to hear the sound through separate speakers, cancel the internal amplifier.

The volume and **MUTE** buttons do not operate when the **Speaker Select** is set to **External Speaker**.

If you select **External Speaker** in the **Speaker Select** menu, the sound settings will be limited.

☐ **Sound Reset → Reset All / Reset Sound Mode / Cancel**

You can restore the Sound settings to the factory defaults.

Selecting the Sound Mode

You can set the sound mode in the **Tools** menu. When you set to **Dual I II**, the current sound mode is displayed on the screen.

	Audio Type	Dual I / 2	Default
A2 Stereo	Mono	MONO	Automatic change
	Stereo	STEREO ↔ MONO	
	Dual	DUAL 1 ↔ DUAL 2	DUAL 1
NICAM Stereo	Mono	MONO	Automatic change
	Stereo	MONO ↔ STEREO	
	Dual	MONO ↔ DUAL 1 DUAL 2	DUAL 1

If the stereo signal is weak and an automatic switching occurs, then switch to the mono.

This function is only activated in stereo sound signal. It is deactivated in mono sound signal.

This function is only available in TV mode.

■ **Digital NR → Off / Low / Medium / High / Auto**

If the broadcast signal received by your TV is weak, you can activate the Digital Noise Reduction feature to help reduce any static and ghosting that may appear on the screen.

When the signal is weak, select one of the other options until the best picture is displayed.

■ **HDMI Black Level → Normal / Low**

You can directly select the black level on the screen to adjust the screen depth.

This function is active only when the external input connects to HDMI (RGB signals).

■ **Film Mode → Off / Auto**

The TV can be set to automatically sense and process film signals from all sources and adjust the picture for optimum quality.

Film Mode is supported in **TV**, **AV**, **COMPONENT** (480i / 1080i) and **HDMI** (480i / 1080i).

☐ **Picture Reset → Reset Picture Mode / Cancel**

Resets all picture settings to the default values.

Select a picture mode to be reset. The reset is performed for each picture mode.

- **Reset Picture Mode:** Current picture values return to default settings.

Using Your TV as a Computer (PC) Display

Setting Up Your PC Software (Based on Windows XP)

The Windows display-settings for a typical computer are shown below. The actual screens on your PC will probably be different, depending upon your particular version of Windows and your particular video card. However, even if your actual screens look different, the same basic set-up information will apply in almost all cases. (If not, contact your computer manufacturer or Samsung Dealer.)

1. First, click on 'Control Panel' on the Windows start menu.
2. When the control panel window appears, click on 'Appearance and Themes' and a display dialog-box will appear.
3. When the control panel window appears, click on 'Display' and a display dialogbox will appear.
4. Navigate to the 'Settings' tab on the display dialog-box.
The correct size setting (resolution): Optimum-1360 x 768 pixels
If a vertical-frequency option exists on your display settings dialog box, the correct value is '60' or '60 Hz'. Otherwise, just click 'OK' and exit the dialog box.

Display Modes

Both screen position and size will vary depending on the type of PC monitor and its resolution. The resolutions in the table are recommended.

D-Sub and HDMI/DVI Input

Mode	Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Pixel Clock Frequency (MHz)	Sync Polarity (H / V)
IBM	640 x 350	31,469	70,086	25,175	+/-
	720 x 400	31,469	70,087	28,322	+/-
	640 x 480	35,000	66,667	30,240	-/-
MAC	832 x 624	49,726	74,551	57,284	-/-
	720 x 576	35,910	59,950	32,750	-/+
	1280 x 720	44,772	59,855	74,500	-/+
VESA CVT	1280 x 720	56,456	74,777	95,750	-/-
	640 x 480	31,469	59,940	25,175	-/-
	640 x 480	37,500	75,000	31,500	-/-
VESA DMT	640 x 480	37,861	72,809	31,500	-/+
	800 x 600	37,879	60,317	40,000	+/-
	800 x 600	46,875	75,000	49,500	+/-
VESA GTF	800 x 600	48,077	72,188	50,000	+/-
	1024 x 768	48,363	60,004	65,000	+/-
	1024 x 768	56,476	70,069	75,000	-/-
VESA GTF	1024 x 768	60,023	75,029	78,750	+/-
	1360 x 768	47,712	60,015	85,500	+/-
	1280 x 720	52,500	70,000	89,040	+/-

- When using an HDMI/DVI cable connection, you must use the **HDMI IN (DVI)** jack.
- The interface mode is not supported.
- The set might operate abnormally if a non-standard video format is selected.
- Separate and Composite modes are supported. SOG is not supported.

Setting up the TV with your PC

- Preset: Press the **SOURCE** button to select PC mode.

Auto Adjustment

Auto Adjustment allows the PC screen of set to self-adjust to the incoming PC video signal. The values of fine, coarse and position are adjusted automatically.

- This function does not work in DVI-HDMI mode.

Press the **TOOLS** button to display the **Tools** menu. You can also set the Auto Adjustment by selecting **Tools** → **Auto Adjustment**.



Screen

Coarse / Fine

The purpose of picture quality adjustment is to remove or reduce picture noise. If the noise is not removed by Fine-tuning alone, then adjust the frequency as best as possible (**Coarse**) and Fine-tune again. After the noise has been reduced, readjust the picture so that it is aligned on the centre of screen.

PC Position

Adjust the PC's screen positioning if it does not fit the TV screen. Press the **▲** or **▼** button to adjusting the Vertical-Position. Press the **►** or **►** button to adjust the Horizontal-Position.

Image Reset


You can replace all image settings with the factory default values.

SOUND CONTROL

Configuring the Sound Menu

Mode → Standard / Music / Movie / Clear Voice / Custom

You can select a sound mode to suit your personal preferences.
Press the **TOOLS** button to display the **Tools** menu. You can also configure the sound mode by selecting **Tools** → **Sound Mode**.



- Standard**
Selects the normal sound mode.
- Music**
Emphasizes music over voices.
- Movie**
Provides the best sound for movies.
- Clear Voice**
Emphasizes voice over other sounds.
- Custom**
Recalls your customized sound settings.

Equalizer

The sound settings can be adjusted to suit your personal preferences.

Mode

You can select a sound mode to suit your personal preferences.

Balance

Controls the balance between the right and left speakers.

100Hz / 300Hz / 1KHz / 3KHz / 10KHz (Bandwidth Adjustment)

To adjust the level of different bandwidth frequencies

Reset

Resets the equalizer settings to the default values.

SRS TruSurround HD → Off / On

SRS TruSurround HD is a patented SRS technology that solves the problem of playing 5.1 multichannel content over two speakers. TruSurround delivers a compelling, virtual surround sound experience through any two-speaker playback system, including internal television speakers. It is fully compatible with all multichannel formats.

Audio Language (digital channels only)

You can change the default value for audio languages. Displays the language information for the incoming stream.

- You can only select the language among the actual languages being broadcast.

- While viewing a digital channel, this function can be selected.

Audio Format → MPEG / Dolby Digital (digital channels only)

When sound is emitted from both the main speaker and the audio receiver, a sound echo may occur due to the decoding speed difference between the main speaker and the audio receiver. In this case, use the TV Speaker function.

- The Audio Format appears according to the broadcasting signal.
- While viewing a digital channel, this function can be selected.